

- The concrete pad size should be 4" thick and 3" apron all around base of enclosure.
- Electrical conduits need to be plumbed inside the concrete pad prior to installing the pad. It is critical that the pad is level. (If the pad is not level the doors may not come out easily).
- Allow 36" clearance in front of and behind the pad for easy access to the unit.
- Handling of the booster pump package requires a crane or forklift from underneath or slinging with straps for proper balancing. Gloves should be worn while handling enclosure to prevent injury from any rough or sharp edges.

For proper operation and handling, training will be provided.